

## SKI INSTALLATION INSTRUCTIONS

YAMAHA 2018 & NEWER SNOSCOOT & SRX120  
MOUNTING KIT #76000376

1. Remove Old ski by taking out the OEM Spindle Bolt, Nut and Washers.
2. Set the OEM Ski, Rubber Dampener and hardware aside, as this won't be reused.
3. Install carbide on ski using the manufacturers guidelines & hardware.
4. Insert the rubber dampener into position inside the ski saddle.  
The tall side of the rubber dampener goes towards the back of the ski. (see Figure 2)
5. Place two bushings into the inner saddle of the ski and push outward into the saddles, they will fit very tightly. (see Figure 1)
6. We recommend greasing spindle bolt to prevent corrosion.
7. Use provided 10mm Bolt, Nut and 2 Washers to affix the ski to the spindle. (Figure 2)
8. Repeat steps 1-7 for other ski.

ITEM #	PART #	DESCRIPTION	QTY
1	77000287	DAMPENER - 287	2
2	76000374	BUSHING 10MM	4
3	76000219	WASHER, 1.5" X .406" X .187"	4
4	76000190	METRIC BOLT, 10-1.5 X 130MM HEX	2
5	76000193	METRIC NUT, M10-1.5 NYLOC	2

